

		19 19
LEGEND MOPERTY LINE		VALLCO
street level plan - building		
TREET LEVEL PLAN - CURB	( <u></u>	OWNER - VALLCO PROPERTY OWNER LLC. 965 PAGE MILL ROAD, PALO ALTO, CA 94304
NDERGROLIND PARKING		T. 850-344-1500 ARCHITECTURE - BAFAEL VINOLY ARCHITECTS
RAINAGE BOUNDARY LINE		50 VANDAM STREET. NEW YORK, NY 10013 T. 212404-5060 ADDURTECTION: DAEAD VAND V ADDURTECTS
OPOSED GREEN ROOF -		ARCHITECTURE - RAFAEL VINOLY ARCHITECTS 1033 N. WOLFE ROAD, CUPERTINO CA 95014 1. 409-637-7090
LF TREATING AREA		LANDSCAPE ARCHITECTURE - OLIN PARTNERSHIP LTD. 150 S. INDEPENDENCE MALL W. SHITE 1123, PHILADELPHIA, PA 19100 7. 214-445-0330
PERVICUS AREA ON GREEN ROOF, ILDING PODIUM OR NATURAL GRADE - LLECTED AND SENT TO CAPTURE		CIVIL - SANDIS CIVIL ENGINEERS SURVEYORS PLANNERS. INC. 1700 S. WINCHESTER BLVD. SUITE 200 CAMPBELL CA \$50.08
		T. 498-636-0800 TRANSPORTATION ENGINEERING - ARUP NORTH AMERICA, LTD
NDSCAPE AREA NOT ON GREEN OF OR PODIUM STRUCTURE - IF TREATING AREA/ CAPTURE		500 MISSION STREET SUITE TIO SAN FRANCISCO CA 94105 T. 415-957-9445
oposed cisternis in basement		UGHTING - ONE LUX STUDIO 156 WEST 29TH STINLET INTH FLOOR, NEW YORK, NY 10001 1212-301-578 BIDNAGE - EX.IT 1617 AF RUIDO SUITE 1665, PHILADELPHIA, PA 19103 1215-961-1800
TOTAL SITE D	AINAGE AREAS	PARKING ENGINEERING - WATRY DESIGN, INC. 2099 GATEWAY PLACE SUITE 550, SAN 205E CA 95110
PROPOSED GREEN ROOF - SELF TREATING AREA	17.231 ACRES	T.405-392-7900
IMPERVIOUS AREA ON GREEN ROOF, UILDING PODIUM OR NATURAL GRADE COLLECTED AND SENT TO CAPTURE	29.084 ACRES	
LANDSCAPE AREA NOT ON GREEN	5 (200 Y// 201)	
ROOF - SELF TREATING AREA/ CAPTURE	4.508 ACRES	
3 STORMWATER TH THE MANDRITY OF THE STE IS COME STE WILL BE SELF TREATING AND S TO OTHER STORM WATER TREATMENT		
SECTION OF THE STE WILL BE SENT		
4	EE	
S. LITTETT		
1 Jan I		
200		
	-	
		ALL STORY CON
		No. CE8315
		a ce anara a
		C O OLIO
		NOT FOR CONSTRUCTION
		DISCLAIMER THE ARCHTECT / ENGINEER SHALL HAVE NO RESPONSIBILITY FOR ANY LIABULITY, LOSS, COST, DAMAGE OR EXPENSE ARISING FROM OR RELATING TO ANY USE OF THIS DOCUMENT FOR ANY
	At an an	
l le	修美港原	PROJECT. THIS DOCUMENT IS TO BE CONSIDERED IN CONJUNCTION WITH ALL RELATED DOCUMENTATION. ANY DISCREPANDES IDENTIFIED IN THIS DOCUMENT MUST BE
		REPORTED INMEDIATELY TO THE ARCHITECT BEFORE PROCEEDING. CONTRACTORS MUST VERIEY ALL DIMENSIONS PRORT TO PROCEEDING WITH ANY WORK ONLY FIGURED DIMENSIONS ARE TO BE USED FOR VERIFICATION.
CLEE		DMENSIONS ARE TO BE LIBED FOR VERIFICATION.
STEVENS CHEEK BOULEVARD	1 1015 222	
	E Dummer	SB -35 DEVELOPMENT APPLICATION
S C	* -	
		REV         DESCRIPTION         DATE           REV/0         58-35 DEVELOPMENT APPLICATION         03/27/2018
	f -	
		([]]
		S S H
		KEY PLAN AND NORTH APROVI
		ARCHITECTS PROJECT NUMBER 70811
	- Fi	PROJECT PHASE: SB-35 DEVELOPMENT APPLICATION IF THIS DRAWING IS NOT 35 WHY IT IS A REDUCED PRINT
	1	IF THIS DRAWING IS NOT 30"WAY IT IS A REDUCED PRAT: REFER TO GRAPHIC SCALE
	11-1	0 32 84 128 182 SCALE 164**7-2
1.14		
		STORM WATER MANAGEMENT PLAN - STREET LEVEL
		SPEET TITLE

#### CISTERN SIZING CALCULATIONS BY DRAINAGE AREAS:

using th	ie U	RQM Approach				
Step 1.		Drainage Area fo	PMD.	17.00	acres	
Step 1.		Drainage Area to	FBMP:	17.02	acres	
Step 2.	a.	Impervious Area:		9.92	acres	
		Impervious ratio:		56.3%		
Stop 2	are b	ned runoff Coefficie	nt Our =		0.382	
otep o.	21.01	(Cw = 0.858i <sup>3</sup> -0.7	i+0.04)	0.002		
		(011 - 0.0001 -0.1	01 -0.774			
Step 4.		Mean Annual Pre	ecipitation	16	inches	
Step 5.		Closest Rain Ga		- less Aless		
oreb o.		Gage	MAP <sub>ance</sub>	an Jose Airpa (P <sub>6</sub> ) <sub>osoe</sub> (in)	м	
		San Jose Airport		0.512		
		Palo Alto	13.7	0.522		-
		Morgan Hill	19.5	0.76		
					_	
		MAPose	13.9			
		(P6)page	0.512			
Step 6.		Mean Storm Eve	nt Precipit	ation Depth	(P <sub>6</sub> ) <sub>ute</sub>	
		$(P_6)_{ste} = (P_6)_{gage}$	X (MAPsit	(MAP <sub>gage</sub> )	0.589	inches
Step 7.		"a" regression co				
Step 7.	0.0	48 hour	1.963		48 hour	
		24 hour	1.582		40 HOUI	1.963
		12 hour	1.312		0-	1.000
		Maniation of Ohmer				
Step 8.		Maximized Stora P <sub>n</sub> =(a X Cw) X P			0.440	incher
		Po =(a XOW) XP	6		0.442	Inchet
Step 9.		Volume of Runof	to be Tre	ated		
		Design Volume =	PoXA	(1ft/12in	0.649	acre-f
					28,254	cuft
Step 10	_	Double Volume f	or Back to	Back Storm		
erep io				1.297	acre-f	
					56,509	cut
Step 11		Size Cistem				
orep 11		Assume 25' Tall	X 12' Wide			
				Length =	190	ft
		Total Cistern Sto				
					57,000	cuft

using th	ne U	RQM Approach				
Step 1.		Drainage Area fo	r BMP:	11.32	acres	
Step 2.		Impervious Area:			acres	
	b.	Impervious ratio:	(i)	63.3%		
Step 3.		Matombod ou	off Coofficie	0.0	0.435	
step 3.		Watershed runoff Coefficient Cw = (Cw = 0.858i <sup>3</sup> -0.78i <sup>2</sup> +0.774i+0.04)			0.433	
		(CW = 0.0001 -0.	01 +0.7741+	0.04)		
Step 4.		Mean Annual Pr	cipitation	16	inches	
orop is			-orproduction			
Step 5.		Closest Rain Ga			ise Airpor	t
		Gage	MAPgage	(P <sub>6</sub> ) <sub>page</sub>		
		San Jose Airport		0.51		
		Palo Alto	13.7	0.52		
		Morgan Hill	19.5	0.76	3	
		MAPage	13.9			
		(Pc)page	0.512			
Step 6.		Mean Storm Eve	nt Precipitat	ion Depth	Pelvin	
		$(P_6)_{abe} = (P_6)_{abbe}$				inche
		e uvine e uvjage	Free a street	free of Bulley		
Step 7.		"a" regression cr	onstant			
		48 hour	1.963		48 h	our
	8=	24 hour	1.582		8=	1.963
	a=	12 hour	1.312			
_						
Step 8.		Maximized Store				
		Po =(a X Cw) X F	6		0.504	inche
o		Volume of Runol	the bar Treat			
Step 9.		Design Volume			0.475	nore f
		Design volume	- TVAAAI	0.1211	20.693	
				-	20,000	vult
Step 10	i	Double Volume 1	or Back to B	ack Storm		
					0.950	acre-f
					41,386	cuft
Step 11		Size Cistem				
		Assume 15' Tall			105	
		7		ingth =	165	π
		Total Cistern Sto	rage Volum		10.075	
					42,075	



## NOTE:




HMP APPLICABILITY MAP

CITY OF CUPERTINO

Logend

sheds 2 65% imperviousne








١E	NO'	TE


THE STE IS CHRONITLY LOCATED IN FOOD 7006 X ACCORDING TO THE FEM. THE OT INCOMPANY INTERVIEW AND A DATA STATES AND A DATA STATES THE OT INCOMPANY INTERVIEW AND A DATA STATES AND A DATA AREAS OF IX AND A DATA STATES AND A DATA STATES AND A DATA AREAS OF IX AND A DATA STATES AND A DATA STATES AND A AREAS OF IX AND A DATA STATES AND A


	VIEWS-VALCOPROPERTY OWNER LIC POWNER-VALCOPROPERTY OWNER LIC 19 CONTRACTOR OF A CONTRACT OWNER LIC 19 CONTRACTOR OF A CONTRACT OWNER LICE 20 VALUES OF A CONTRACT OWNER CONTRACT 20 CONTRACT OWNER LICE 20 CONTRACT OWNE
NG TO THE FEMA Defectorian J. DATED BOY STATES S OF LESS TANK 1 AND AREAS	
	SB -35 DEVELOPMENT APPLICATION
STORM WATER MANAGEMENT PLAN - DETAILS NO SCALE	r-0404 Sheet Number:























- Entrenes (Evit. TO 1
n Entrance/Exit TC-1
shed oggregate greater than 3" smaller than 6"
ter fabric grade Ness atherwise a soils engineer
<u>N B-B</u>
ct sediment borrier nnelize runoff to t trapping device □B
Width as required to accomadate anticipated traffic
y pipe culvert B
n e circumference truction vehicle tire, is groator
AN S
ater BMP Handbook 5 of 6 ruction sqa.org



WATER POLLUTION CONTROL DETAILS NO SCALE

e Santa Clara Valley, storm drains flov ctly to our local creeks, and on to San cisco Bay, with no treatment. Storm water pollution is a serious problem wildlife dependent on our waterways and fu he people who live near polluted streams avlands. or management of construction sites ces pollution significantly. is sheet summarizes the "Best Mana actices" (BMPs) for storm water polls

ORDINANCE OF THE CITY OF CUPERTINO FOR STORM WATER POLLUTION **PREVENTION & WATERCOURSE** PROTECTION Chapter 9.18

9.18.040 Discharge into the storm drain prohibited It is unlawful to cause, allow, or permit to be discharged, any discharge not composed entirely of stormwater to the storm drain system or to surface waters or to any location where it would contact or eventually be ransported to surface waters, including flood plain areas, unless specifically called out in the Municipal Regional ermit as an exempt or conditionally exempt discharge. 9.18.070 Accidental Discharge

All persons shall notify the Director of Public Works immediately upon accidentally discharging pollutarts of concern to enable countermeasures to be taken by the City to minimize damage to storm drains and the receiving waters. Initial notification shall be followed, within five (5) business days of the date of occurrence, by a detailed business upp of the label of dictimence, by a becauted written statement describing the causes of the accidental discharge and the measures being taken to prevent future occurrences. Such notification will not relieve persons of liability for violations of this chapter or for any fines impos on the City on account thereof under Section 13350 of the California Water Code, or for violation of Section 5650 of the California Fish and Wildlife Code, or any other applicable rovisions of State or Federal laws

#### 9.18.220 Violation\*

Any person who violates any provision of this Chapter shall be guilty of a misdemeanor and upon conviction thereo shall be punished as provided in Chapter 1.12 of the City of Cupertino Municipal Code

Chapter 1.12: General Penalty, Section 1.12.010, paragraph D, states\*.

Unless otherwise specified by this code, an infraction is by: A fine not to exceed \$100 for a first violation

A fine not to exceed \$200 for a second violation A fine not to exceed \$500 for a third violation of the same chapter within one year.

violation occurs

\*Excerpts - For complete CODE language refer to the City of Cupertino Municipal Code.

upertino Building Dept: 408-777-3228 Public Works Dept: 408-777-3354 anta Clara County Recycling Hotline: 800-533-8414 www.recyclestuff.com Small Business Hazari 408-259-7300 ous Waste upertino Sanitary Sewer Distr 498-253-7071

Santa Clara Valley Urban Runoff Pollution Prevention Prgm 800-794-2482 tate Office of Emergency Services 1-800-852-7550 (24 hrs)

9/1/16

eport spills to 911

W BORD

General Construction and Site Supervision Storm Drain Pollution from Construction Activities rudion killes are common sources of stor poliution. Materials and washes that blow into a storm drain, gutter, or stevel have a impect on local oneirs and the Bay. tom dave, coels, or Channels, Contain all littler, food wappens, bottles and case. Place lobel rash and recycling bre-arourd the whit. Chan up table, drops and other splits emodaling is offered on the sufficient control of the second second second second black by control of the second second second black by control of the second second second out down. contractor, or site supervisor, owner or ator of a site, you may be responsible for anononmental damage caused by your Seneral Principles Keep an orderly site and ensuer goot housekeeping practices are used. dat down.
Cover and maintain dumpstees. Place dumpstees under notifie or oner with targe state is thereing secure a round the outlied targets in New roles out a dumpster by down on the constructionster. Maintain equipment property
 Gover materials when they are not in use Keep materials away from streets, storn drams and distracte channels. dennis and damarge homensis. — Ennis e data control sales doenn't laves sale or tabonarge is skorn daans. Advancer Reinzerig for Howener Pallacition → Schecke excenden and ges drug advities ensisten gaar leinoroom yvogstelen op beso utbere rocken cantidat before sain hoges. Une the Esson on discherer Control Mexau paulitats term the Regional Weble Cushity — Control the mount of another Cushity Place portable failets away from storm drams. Make sure portable to lets are in good working order. Check/inguanity for letika. MaterialsWaste Handling Practice Source Reduction --minimum waste
when you other material. Estimate carefully Recycle excess materials, wherever possible such as concrete, suphar, scop metal, solvertis, depresent, cleaned vegetation, paper, sock, and whole maintenance materials such as used of, anthesize, taitaines, and keep metal indepresent materials and as used of, anthesize, taitaines, and keep. Control Bloant, as a reference. Control the second of nuclifications of proof being propedity camp execution by surge-beings of theory are for an uncertain the constructing barry of an entered the second constructing barry and the second camp of the second camp barry and the second camp of the second camp barry and the second camp and the second camp barry and the second camp and the second camp barry and the second camp camp barry and the second camp barry and the second camp barry and the second camp barry and camp barry and the second camp barry and

Dispose of all wastes property Muterials/hat cannot be excited must be taken to an appropriate landfill or disposed of as hazardous meets. Never Duty waste materials or leave them is the sheet or near a creation of them thed. In addition to logal grading and building permits, you will need to obtain coverage under the State's Canesal Construction Activity Stormwale Primit 4 contest construction activity adom-your construction with a distlucted-acres or more, information on the can be obtained from the Regional Control Board. (This onterin will the acre is of Mar. 2003)

Landscaping, Gardening, and Pool Maintenance

yardwaste on site themselves. Or tak yardwaste to a land \$1 shere it will be composed.

take clopings and pruning wasle to a landfill that composts yard waste (BFTs Nawby latend and Zanker Rd, landfill are the neares

Do not blow or rake leaves into

Landscape contractors

Lands caping/Garden Maintenance discharged to storm toxic to aquatic Me. Protect stockpiles and landscaping materia from wind and rain by storing from under targe or secure blastic operation Schedule gradnig and entavation projects during dry weather Use temporary check dams or ditches to divert runoff away from storm drains. Protect storm drains with sandbags, gravet-filled bags, straw wattles, or other sedment controls.

Re-vegetation is an excellent form of erosio control for any site. Store pesticides, lettilizers, and other chemicals indoors or in a shed or storage cabinet cabinet
Get pesticides sparingly, according to
mstructors on the labs. Rinse empty
means and use intervalte as pro-

ordinance Never discharge pool or spa water to a street or above drain; discharge to a santary sever cleanoot. It possible when engine or a leve days and then recyclewares when by detaining it gradual onto a landscaped ama. In Cuperino, residents with curbs can collect lawn, parden and tree to yardwasts toters. Yardwaste will b and composited by the city's contrac Residents are encouraged to compri-

Do not use copper-based algoecides Control argze with chice ne or other alternatives, such as sodium bromide. Filter Cleaning Never clean a filter in the street or near a storm drain. Rise carhinge and

If there is no suitable dirt area, coll Cupartine Sanitary for instructions on. Cupertine Sanitary b discharging filter back the sanitary server.

Storm Drain Pollution from Landscaping and Swimming Pool Maintenance May landscaping activities receives icks and nones he kelhood hat each and parken benedas withing activities receives icks and nones he kelhood hat each and garken swimming pool weer costse ing choine and coper oaeed algeedess should never be discharged tostym daws. These chemicals and scharged tostym daws. These chemicals and Earth-Moving Activities Storm Drain Pollution

from Earth-Moving Activities Soil excevation and grading operations loosen lang amounts of soil that can flow or blow into storm crans when handled improperly. Sedimetris in runcht can dog storm drains umoher aquatic life, and cestroy habitats in creeks and the Bay. Effective troision control practices reliaes the amount of the store for an effective store of the store Pool/Fountain/Spa Maintenance

Draining pools or spas When it's time to drain a pool, spa, or fourtain please be sure to call the Coperino Santary Disk to before you start for further guidance on flow rate metricitions, backflow prevention, and flow rate metricitions, backflow prevention, and erosion control practices reduce the amount o crossing a site and slow the flow with check d roughened ground surfaces.

handing spicol cleaning waste (such as acid wash). Discharge flows should be kept to the ti le versitypically possible through a garden hole Higher flow railes may be prohibited by local ordnance. Practices During Construction Remove existing vegetation only when absolutely necessary. Plant temporary vegetation for encolor control on slopes or where construction is not immediately planned.

Protect downslope drainage courses streams, and storm drains with wattles.

streams, and storm drains with withins, or temporary formings swales. Use check dams or dtches to divert runoff around excavations. Refer to the Regional Water Quality Control Boards Ensoin and Sedment Control Field Manual for proper ensoin and sediment control

Cover stockpiles and excavated soil with secured targs or clastic sheeting.

Storm Drain Pollution

from Roadwork

Road paving, surfacing, and pavement removal happen right in the street, where there are nume opportunities for asphalt, saw-cut slurry, or excavate d material to ling ally enter storm drains. Estra planning is required to store and dispose of materials properly and guard against pollution of storm drains, creaks, and the Bay.

Avoid paving and seal coating in wet weather, or when rain is forecast, to prevent tresh materials from contacting stormwater

Cover and seal catch basins and manholes when applying seal cost, slurry seal, fog seal, or similar materials.

or sim flar materials. Protect drainage ways by using earth dikes, sand bags, or other controls to divert or thap and filter runoff. Never wash excess material from exposed-aggregate concriste or unifar treatments anto a streed or a form duin. Collect and recycle, or diapose bo dri arkes.

Cover stockpiles (asphalt, sand, etc.) and other construction materials with plastic targs Protect from rainfall and prevent runoff with temporary roofs or plastic sheets and berms

During Construction

diatomaceous earth fillers onto a dirt area, and spade filter residue into soil. Dispose of spent diatomaceous earth in the garbage

The property owner and the contractor share ultimate responsibility for the activities that occur on a construction site. You may be held responsible for any environmental damage caused by your subcontractors or employees.

Painting and Le. Application of

Solvents and Paint Removal Paint chips and dust from non-hazardous dry stipping and sand blasting may be swept upor collected in plastic drop cloths a disposed of as trash. Adhesives

Handling Paint Products

Never clean brushen or rinse paint containers into a street guilter, storm drain, French drain, or creek.

For water-based paints, pant out brushes to the extent possible, and make into an inside salk-drain that goes to the sandary seven

For oil-based paints, paint out brushes to the extent possible and clean with thinner or solvent. Filter and reuse trivners and solverts, where possible. Depose of excess liquids and residue as hazardous waste.

When thoroughly dry, empty paint cars, use brushes, rags, and drop dofts may be disposed of as nathang.

Painting Cleanup

Chemical paint stripping mixibue, and chon and dust from marine paints, or paints containing back, mencury or tribusyl tim mus be deposed of as hazandous washes. Lead based paint nemoval regums a slate-certified continuous. Storm Drain Pollution from Paints Storm Drain Pollution from Pai solvents, and Adhesives All parts, solvents, and adhesives tontain chemicals that are harmful to widthen to call easels. Sen Francisco Bay, and the Pacific Or Toke chemicals may come from legislor existio products or home learning residues or rags. Per material and waters, adhesives and clearing to hotal at the incident when consider, or discours

Unmittee. 3 When stopping or cleaning building extent with high-pressure water. Slock storm dram. Direct washwater onto a dr1 area and ga-roto sol. Or, thock with Cupering Sinday Diskict to find out 5 you can mop or vacuum washwater and dispose of it in a sandary seever drain. Sampling of the washwater may be required.

be required Washwater from painted buildings constructed before 1978 can contain high amounts of Lead, even if paint chpis are no present. Before you begin stripping paint or cleaning pre-1978 building exteriors with wir under high pressure, test paint for lead by Keep all liquid paint products and wester away from the gutter, street, and storm drains.

taking paint scrapings to a local laborati (See Yellow Pages for a state-certified laboratory.)

If there is loose paint on the building, or if the paint tests positive for lead, block storm drains. Chock with Capatitin Sanitary Datiid to determine whether you may decharge with both sanitary server, or if you must start of blate for disposal as hear dous winter

Paint Disposal, Return or Donatio Dispose of unwanted kaud paint, thinnen, solvents, glues, and desring fluids as hazardous waste (call the Small Business Hazardous Waste Prigm, 299-7300).

Or Return to supplier. (Unopened cans of pa may be able to be returned. Check with the wendor regarding its "buy-back" policy.)

Donate excess paint (call 299-7300 to donate.)

CONSTRUCTION BEST MANAGEMENT PRACTICES

## Roadwork and 0 Paving General Business Practices

Develop and implement erosion/sediments control plans for roadway embankments Schedule excavation and grading work during dry weather.

# Check for and repair leaking equipment Check for and repair reaking equipment. Perform major equipment repairs at designated areas in your maintenance yard where cleanup is easier. Avoid performing equipment repairs at construction sites

 When m fueling or when vehicle aquipment maintenance must be done on site, designate a location away from storm drains and creeks.
 Oo not use diesel oil to fubricate equipment parts or clean equipment. parts or clean outportent Recycle used oil, concrete, broken asphalt, alc, whenever, possible, or dispose of propert (www.recyclestuff.com for list of recycling companies.)

Asphalt/Concrete Removal

Avoid creating excess dust when breaking asphalt or concrete.

 After breaking up old pavement, be sure to remove all chunks and pieces. Make sure broken pavement does not come in contact with rainfall or runoff. When making saw cuts, use as little water as possible. Shovel or vacuum saw-cut slows and

possible. Shovel or vacuum saw-cut stury and remove from the site. Cover or protect storm drain inlets during saw-cuting. Sweep up, and properly dispose of, all residues

Sweep, never hose down streets to clean up tracked dirt. Use a street sweeper or vacuum truck. Do not dump vacuumed liquor in storm drains.

Park paving machines over drip pans or absorbent material (cloth, rags, etc.) to catch drips when not in use. Clean up all spills and leaks using "dry" methods (with absorbent materials and/or rags), or dig up, remove, and properly dispose of contaminated soil.

Collect and recycle or appropriately dispose of excess abrasive gravel or sand. ???
 Avoid over-application by water trucks for dust control.

# Dewatering Operations

# Storm Drain Pollution From Dewatering Activities

Be sure to call your city's storm water inspector at 400-472-9907 before discharging water to a steet, guiter, or storm drain. Fartation or diversion twoogh a basin, tank, and sedment trap may be required. Revues water for duits control, irrigation or another on-sile purpose to the greatest exten possible.

# Check for Sediment or Toxic Pollutants

Check for odors, discoloration, or an oily sheen on groundwater. Ask your city inspector whether the groundwater must be tested by a certified laboratory

- Depending on the test results, you may be allowed to discharge pumped groundwater to the storm drain OR you may be required to discharge to the sanitary server or collect and haul the water off-site for treatment and
- osal at an appropriate tre When discharging to a storm drain, protect the inite using a barrier of burlap bags filled with drain rock, or cover inlet with filter fabric anchored under the grate.

Contact Cupertino Sanitary District at 253-7071 prior to discharging to the sanitary sewer.

# Removal of BMP Facilities The Project Contractor is responsible for removal of all BMP Facilities located within the Public Right of Way

upon project final inspection.

Fresh Concrete

and Mortar

Applications

General Business Practices

Application 3

# **During Construction** Don't mix up more fresh concrete or certain than you will use in a two-hour period. Set up and operate small mixers on tarps or heavy plastic drog cloths. When cleaning up after driveway or sidewalk construction, wash fines onto dist areas, no down the driveway or into the street or storm drain.

Protect applications of hissh concrete ani montar from rainfall and runoff until the material has dried.

# materialhas Gried. Weak down expensed apgregate some meta only when the washwater can (1) for who a tim sees. (2) down on the beamed auticate from which it can be pumped and desposed of property, or (3) be vacuumed form a authorem created by blocking suborn drain time. If mecasary, diver round drain time. If mecasary, diver round drain time. If washing a sub-round does not reach patters or washing drame.

Never dispose of washout into the street, storm drains, drainage ditches, or streams

City of Cupertino DEPARTMENT OF PUBLIC WORKS

Secure bags of cement after they are open. away from streets, gutters, atorn drains, raintall, and runoff De not use dissel fuel as -









2 Die not und diesert of the Matrix ats equipment parts of clean equipment. Use only water for any entite cleaning. Cover expanded fills wheat blacks and other any or preasy as upment doing take seattle

mmon sources of storm revent spills and leaks b supment from jumpfichs

Any or product an other and thickness and the set of th

Sweep on solid day wateriate in metaloty Never allowed to weat them every with each other state. 2 Das as little water as possible for dust control Ensure water used doesn't leave all or manifested in store dusts.

Clean up apills on distances by organy up and property disposing of contamination sail Call \$11 far significant spills

If the spill posses a significant frazard to human health and safety projectly do the environment, you must also report it to the State Office all first ergency Safetices

Small Business Hazardous Waste Disposal Prgm Businesses that generate les than 27 gallons or 220 pound of hazardous waste per mont re eligible to use this program Call 408-299-7300

a

for a quote.

CUPERTINO

T SECTOR STATE OF CALIFORN NOT FOR CONSTRUCTION

# SB -35 DEVELOPMENT APPLICATION

4 S8-35 DEVELOPMENT APPLICATION 03/27/2018

10 9 8 7 N

ARCHITECTS PROJECT NUMBER THIS DRAWING IS NOT 36"HET IT IS A REDUCED PRIN

BEST MANAGEMENT PRACTICES

P-0413

NOSCALE